



MiniGPS User Manual

Version 1.0

1. Connect your BT-821 to your Bluetooth enabled device.
2. Start the MiniGPS program in the CD supplied on the device.
3. Select the com port and set the baud rate to 115200. Then, click on the “Open” button.



4. Make sure that you place your BT-821 outdoor. Then, click on the “Cold Start” button to test your BT-821.



5. Your BT-821 works properly if it gets a fix.

